

IMPORTANT

For 1989-1993 Trucks being retrofitted with Centerforce P/N DF489989, the supplied bolt kit **MUST** be used.

Torque the supplied bolts to 15-20 ft.lbs.

DO NOT use supplied bolts on 1994-1998 vehicles.

Failure may result by doing so!

199CH004