


IMPORTANT

ISUZU IMPULSE / STYLUS WITH MECHANICAL LINKAGE

THE FOLLOWING PROCEDURES MUST BE COMPLETED TO PROPERLY ADJUST THE CLUTCH. LOOSEN THE ADJUSTING NUT AND ADJUST THE CABLE UNTIL THE FREE PLAY (3) IS BETWEEN 1/32"-1/4". ADJUST THE PEDAL HEIGHT UNTIL IT IS BETWEEN 7 1/4" - 7 5/16".



"NOTE" Centerforce tip sheets are for general reference only. Please refer to your owners manual for vehicle specifications.

IMPORTANT